

# Cheap Office.

Thank you for choosing our product.  
Before inserting the cartridges in the printer, read the instruction below.

For any clarification or tecnica support, contact our costumer service [www.cheapoffice.it](http://www.cheapoffice.it)



1) Remove the front cap from the cartridge, positioning the cartridge with the aperture face up.



2) Insert the dispenser spout of the ink bottle in the hole, keeping it in vertical position.



3) Unscrew counter-clockwise the dispenser spout to allow the ink to flow.



4) Squeeze the ink bottle until exhausted to fill the inkbag of the cartridge leaving a little space between the dispenser spout and the aperture to facilitate the air leak.



5) Close the aperture with the specific cap.



6) Insert the specific plastic spout on the end of the syringe.

## INSTALLATION GUIDE Eps cartridge with inkbag SURE COLOR

SC T 3000 - 5000 - 7000 WITH AUTO RESET CHIP  
SC T 3200 - 5200 - 7200 WITH ONE TIME CHIP  
SC S 30600 - 50600 CON WITH TIME CHIP  
F 2000 WITH ONE TIME CHIP



7) Insert the syringe in the ink's outlet valve.



8) Aspirate excess air in the inkbag. To do this aspirate at least 15ml of ink then empty the syringe in the bottle and repeat the operation.



9) Insert the cartridge in the specific slot of the printer then close the cover

**IMPORTANT NOTE:** Before the printing ALWAYS check that the remaining amount of ink is enough to avoid that the cartridge go completely out of ink.

DISTRIBUTED BY  
CHEAP OFFICE  
tel. 0522260545 - Fax. 0522524725  
[www.cheapoffice.it](http://www.cheapoffice.it)

**IMPORTANT NOTE: only for models: SC T3200, 5200, 7200**


**WORKING PRINCIPLES AND APPLICATION OF ONE TIME CHIPS IN  
EPSON Sure Color T3200/5200/7200 PRINTERS**

ONE TIME CHIPS ARE EQUIPPED WITH A SERIAL NUMBER.  
FOR EACH CHIP IS INDICATED ON THE LABEL THE COLOR AND THE SERIAL NUMBER  
(example. IN THE PHOTO: THE COLOR IS PHOTO BLACK AND THE SERIAL NUMBER IS 19).

**THE PRINTER WILL RECOGNISE THE SERIAL NUMBER  
ONLY ONCE,  
SO EVERY TIME YOU WILL ORDER THE CHIPS IT WILL BE  
NECESSARY TO COMMUNICATE US THE SERIAL NUMBERS  
YOU HAVE ALREADY RECEIVED.**

CHEAP OFFICE RELIEVE ITSELF OF EVERY RESPONSABILITY FOR  
THE UNRECOGNISED SERIAL NUMBERS BECAUSE OF NOT COMMUNICATED

**NEVER PERFORM FIRMWARE UPDATES**



DISTRIBUTED BY

CHEAP OFFICE  
tel. 0522260545 - Fax. 0522524725  
[www.cheapoffice.it](http://www.cheapoffice.it)